

1


Please decide if you will need to top-fix or face-fix the Roller Blinds. The brackets protrude by 120mm when top-fixed or 105mm when face-fixed. If you have window handles or vents that stick out from the window frame, measure how far these protrude and add this to the bracket depth. This will be used as measurement (A).

You will need:-

- 2 no. Pieces of A4 or A5 sized paper or card.
- Pencil.
- Metal Tape-measure.
- Ruler.


2

Using two pieces of paper, place them edge to edge and mark both of them at the required measurement (A).




3

Slide the two pieces of paper towards each other along the window sill of the bay until the two marks that you made meet up.




4

Using a pencil, make a mark on the window sill at the point where the paper meets the window frame.



5

Measure from one mark to the next as detailed in the diagram. This will establish the width of the blind that you will need to order.



6

Measure the drop from where the top of the blind will sit down to where you want the blind to end (typically the window sill). All of the blinds should then be ordered as 'exact fitting' with the 'bracket to bracket' option selected.