


Install the brackets


1



Place the bracket flat to the glass and push it in towards the frame ensuring that it slides under the rubber/mastic seal. Push it in as far as possible. Repeat for each corner of the window.


Fit the blind

2



Clip the head-rail onto the brackets at the top of the window by aligning the rail with the bracket and pushing the rail towards the glass until you hear it click into place.

Hook the cord through the centre of the lower bracket on both sides of the window. The cord should be running straight down, hooking around to pass through the centre of the bracket and then across the bottom of the window when done.




To finish, clip the bottom-rail into the lower brackets by aligning the rail with the bracket and pushing firmly towards the glass until you hear it click into place.

If you need to adjust the tension

3


Over time the cords may slacken off and need retensioning.

You'll know when it's time to retension as the blind will begin to slip back down when raised.




Start by removing the bottom bar - to do this, slide it upwards from one corner, to slide the bracket out from under the seal.

Then remove the brackets from each end of the bar to free it and pop the bar to one side.



Slot the brackets back into the corners as per step 2.



The cord is attached to each end of a small spring. Untie one end and pull through further to increase the tension in the cords.

Pull through by around 5-10mm, then give the blind a test to see if the tension is right. Repeat as necessary, then when the tension is correct, clip the bottom bar back on as per step 2.