




We've made a handy video version of this fitting guide, just click the play button to view it.

If you prefer to print the instructions or simply to follow step-by-step, just keep reading.

Installing the brackets

1




Push the bracket firmly into place between the glass and the rubber seal.


Place the brackets flat to the glass and push them in towards the frame, ensuring that they slide in under the rubber/mastik seal. Push in each bracket as far as possible, with one bracket in each corner of the glass.

Installing the blind

2



Clip the headrail onto the brackets at the top of the window by aligning the rail with the brackets and pushing the rail back towards the glass until you hear it click into place.




Hook the cord through the centre of the lower bracket on both sides of the window. The cord should be running straight down the edge of the glass, hooking around the bracket. Make sure it's passing through the centre of the bracket and then straight across the bottom of the window.

To finish, clip the bottom rail into the lower brackets by aligning the rail with the brackets and pushing back firmly towards the glass, until the rail clicks into place.

Adjusting the tension



3




Over time the cords may slacken off and require re-tensioning. You'll know if the blind needs re-tensioning as it will begin to slip back down of its own accord when raised.

Start by removing the bottom rail - to do this, slide it upwards from one corner, to slide the bracket out from under the seal.

Then, remove the brackets from both ends of the rail and put the rail to one side.



Slot the brackets back into the corners, as per step 1 of this guide.



At the bottom of the blind the cord is connected to both ends of a small spring. On one side, the cord is secured by a metal sleeve with a screw.


Loosen the screw, then pull the end of the cord through by 5-10mm. Tighten the screw and give the blind a test to see if the tension is right. Repeat this as necessary, using small adjustments only, until the tension is correct.

Once you're done, simply click the bottom rail back into place.


IMPORTANT: To avoid damaging the cord, make sure that you do not over-tighten the screw.

Fitting optional grip pads


4



If you find that the brackets slip against the glass and do not hold their positions in the very top and bottom of the window, then you can use the provided grip pads to help them stay in place.



Start by taking one of the pads and, using a pair of scissors, cutting into roughly 10mm segments.



Remove the blind and brackets from the window. Take one of your cut segments, peel off the backing paper and stick the segment to the flat face of the bracket that sits against the glass. Peel off the protective film on the front of the segment, then carefully reinsert the bracket in the window. Press each bracket firmly against the glass for around 30 seconds once reinserted, to allow the adhesive on the grip pad to bond.