

Measuring Guide

Blackout Pleated Blinds with Side Tracks


Measuring for your new blinds is easier than you might think! All you have to do is follow our simple tips, double-check everything you do, and set aside some time to do it. Happy measuring!




Standard Windows

Recess fitting

Measure the full width and height of the recess [the size of the hole if you like] and we will make the appropriate deductions to ensure a perfect fit.




- Measure in 3 places for both the width and the drop, use the smallest measurement
- **Don't make any deductions**, we'll deduct a small amount from the width and drop to ensure your blind fits perfectly. For TotalShade & MaxShade Blinds we'll deduct a total of 4mm, and for Click2Shade Blinds we'll deduct just 1mm.
- **Use a metal tape measure**, cloth ones can stretch and give you inaccurate measurements



Exact fitting (not applicable for Click2Shade Blinds)

Measure the full width and height of the recess [the size of the hole if you like] and add a little extra to the top and to each side, we will make the blind to the size you specify with no deductions.



- To minimize light leakage we recommend that the blind overlaps the window recess by at least 70mm at the top and 50mm each side
- The overlap at the bottom of the blind is a matter of personal choice but please **take into account obstacles** such as radiators

Top-Tip:

If you are **replacing an existing blind** with one of the same size, simply measure the blind (including its fittings) and specify exact fitting, we will make you one the same size.

